

Jan 24, 2000



SERVICE BULLETIN

SEGA Service Department
45133 Industrial Drive
Fremont, Ca. 94538

<http://www.seuservice.com>
Phone: 415.701.6580
Fax: 415.701.6594

SEGA Bass Fishing™ ALL CABINET STYLES

PROBLEM: Torq and wear applied to Bass Fishing handle causes an M3x8 screw (located near the 'butt' end of handle) to work it's way loose.

SOLUTION: Apply a small amount of blue loctite to screw before reinserting it.

NOTE: Do not replace with longer screw, as this can pierce the wire harness located within the handle assy, causing a short circuit and/or failure.

USE BLUE LOCTITE
PART NO. 242

