

**WARNING: READ BEFORE USING YOUR SONY® PlayStation™  
GAME CONSOLE**

A very small percentage of individuals may experience epileptic seizures when exposed to certain light patterns or flashing lights. Exposure to certain patterns or backgrounds on a television screen or while playing video games, including games played on the PlayStation game console, may induce an epileptic seizure in these individuals. Certain conditions may induce previously undetected epileptic symptoms even in persons who have no history of prior seizures or epilepsy. If you, or anyone in your family, has an epileptic condition, consult your physician prior to playing. If you experience any of the following symptoms while playing a video game — dizziness, altered vision, eye or muscle twitches, loss of awareness, disorientation, any involuntary movement, or convulsions — IMMEDIATELY discontinue use and consult your physician before resuming play.

**WARNING TO OWNERS OF PROJECTION TELEVISIONS**

Still pictures or images may cause permanent picture-tube damage or mark the phosphor of the CRT. Avoid repeated or extended use of video games on large-screen projection televisions. Refer to your projection TV instruction manual for more details.

**Handling Your PlayStation DISC**

- This compact disc is intended for use only with the PlayStation game console.
- Do not bend it, crush it or submerge it in liquids.
- Do not leave it in direct sunlight or near a radiator or other sources of heat.
- Be sure to take an occasional rest break during extended play.
- Keep this compact disc clean. Always hold the disc by the edges and keep it in its protective case when not in use.
- Clean the disc with a lint-free, soft, dry cloth, wiping in straight lines from center to outer edge. Never use solvents or abrasive cleaners.

**VIACOM**  
newmedia


1515 Broadway  
New York, NY 10036  
1-800-469-2539



Hookstone


© 1995 Viacom International Inc. All rights reserved.  
© Original game concept © 1995 Hookstone Ltd. Patent Pending  
Developed by Hookstone Ltd, 4 Grove Park Court, Grove Park  
View, Harrogate, North Yorkshire HG1 4DP UK

# contents




<b>Getting Started</b>	• • • • •	<b>2</b>
<b>Controls</b>	• • • • •	<b>3</b>
<b>Screen Display</b>	• • • • •	<b>3</b>
<b>Objective</b>	• • • • •	<b>4</b>
<b>Power-Ups</b>	• • • • •	<b>5</b>
<b>Menu</b>	• • • • •	<b>6</b>
<b>Settings</b>	• • • • •	<b>6</b>
<b>Scoring</b>	• • • • •	<b>7</b>
<b>Options</b>	• • • • •	<b>7</b>
<b>High Scores</b>	• • • • •	<b>8</b>
<b>Credits</b>	• • • • •	<b>8</b>
<b>Warranty</b>	• • • • •	<b>9</b>

## getting started



1. Set up your Sony® PlayStation™ game console according to its instruction manual. Plug in a game controller.
2. Insert the **ZOOP™** disc and close the CD door. Always make sure the PlayStation game console's power is OFF before inserting or removing a compact disc.
3. Turn the PlayStation game console ON.

## controls




**MOVE:** Use the Directional Buttons to control the center piece in the center square.

**FIRE:** Press the ○, ×, □, △, L1, L2, R1, or R2 Buttons to fire at the approaching shapes.

**PAUSE:** To pause the game press the START Button.


**RESET:** To reset the game press the RESET Button on the PlayStation game console or hold down the START or SELECT Button for two seconds and the game will reset to the title screen.

## screen display



## objective

Colored shapes randomly appear along the grid, and move toward the center square. You control the center piece within the square. You must eliminate the shapes (remove them from the grid) before they enter the center square. (Figure 1) Firing at and striking a shape that is the same color as the center piece eliminates that shape. (figure 2) If you strike a shape of a different color, the center piece exchanges colors with that shape, and the shape remains on the grid (figure 3).




Once you eliminate the required number of shapes (as indicated by the number in the upper right hand corner), you will move to the next stage, and the play intensity will increase.

**Hint:** For higher scores and faster screen clearing, eliminate multiple shapes at one time. Change the first shape in a row/column to match the shapes behind it – then Zoop them all at once.


**Note:** When the colored shapes are about to enter the center square, the dots in the center square will flash and a warning will sound. If the colored shapes enter the center square, the game will end.

## power-ups


As you play ZOOP, Power-Up Icons will randomly appear on the grid along with the colored shapes. If you strike a Power-Up, it will assist you in eliminating other shapes.




**Proximity Bomb:** Eliminates all the shapes touching the first shape hit.



**Line Bomb:** Eliminates an entire row or column of shapes regardless of color.



**Color Bomb:** Eliminates all the shapes in a quadrant that are the same color as the first shape hit.



**Bonus Springs:** Collect five of the Bonus Springs and they will clear all of the shapes off the grid.

**Note:** If a Power-Up or a Bonus Spring reaches the center square, it will disappear. Power-Ups and Bonus Springs will not end the game.

## menu

**PLAY:** Pressing the X Button while the cursor is on "Play" will begin in the game mode most recently selected. If unadjusted, ZOOP will begin game play at the default settings: Continual, Level - 1, Difficulty - 0.

**SETTINGS:** Pressing the X Button while the cursor is on "Settings" will allow you to access and change the game preferences before playing.

**Note:** Press the X Button to select any option.

## settings

**CONTINUAL:** In a Continual game, once you have eliminated the required number of shapes to move to the next stage (as indicated by the number in the upper right corner), the game background will change, the speed that the shapes appear on the screen will increase, and current shapes will remain on the grid.

Pressing the X Button while Continual is highlighted will take you to the Continual Stage Select and Difficulty Select screen.

**LEVEL:** In a Level game, once you have eliminated enough shapes to end the stage (as indicated by the number in the upper right hand corner), all the remaining shapes will be removed from the grid, the background will change, the speed that the shapes appear will increase.

Pressing the X Button while Level is highlighted will take you to the Level Stage Select and Difficulty Select.

**STAGE:** Use the Directional Buttons to rotate the stage dial to the desired beginning stage. Press the X Button, or down on the Directional Buttons, to select the stage highlighted. In higher Stages, shapes appear on the screen more quickly.

**DIFFICULTY:** Use the Directional Buttons to adjust the difficulty bar to the desired difficulty. Press the X Button to select the difficulty and move back to the options screen. Difficulty determines the number of shapes on the screen at the beginning of game play. At a higher difficulty, more shapes will be placed on the screen.

**Note:** During a Continual Game, the shapes will only be placed on the screen on the opening stage. During Level play, shapes will appear on the screen at the beginning of each stage.

## scoring

### # of Shapes

#### eliminated

#### Total Points

One	100	
Two	300	
Three	600	
Four	1,000	
Five	1,500	(5,000 full vertical column)
Six	2,100	
Seven	2,800	(10,000 Full horizontal row)

## options

Pressing the X Button while Options is highlighted will allow you to adjust the Music and Sound Effects volume in the game.

Use the Directional Buttons to select + or - for the Music or Sound Effects. Pressing and holding down the X Button will adjust the volume louder (+) or softer (-).

To exit the screen, use the Directional Buttons to highlight EXIT, and press the X Button.



# high scores

At the end of each game, a HIGH SCORE screen appears. If you have earned a HIGH SCORE, you can enter your initials by pressing the Directional Buttons Up or Down to choose a letter and then pressing the Directional Buttons to the right to move to the next space. After the initials have been entered, press the X Button to go down to CONTINUE or EXIT. Press the Directional Buttons Up or Down to highlight your selection, then press the X Button to activate your choice.

LEVEL SCORE					
name	score	date	time	level	
GAAGA	0036500	0208	00:03:00	08	
GJAGA	0034900	0231	00:02:55	10	
BAAGA	0020800	0075	00:01:16	06	
AAAAA	0013200	0074	00:01:16	07	

**CONTINUE:** will start a new game with the same settings as the game just played.

**EXIT:** will go to the title screen where settings can be changed for a new game.

# credits

**Designed in the UK by Hookstone Ltd.**

**Programmed by Hookstone and Influence**

**Programmers**

Chris White  
Cliff Davies  
Jason McGann

**Graphic Artists**

Peter Tattersall  
Ian Bowden

**Hookstone Worldwide Representation**

John Cook, Bad Management  
England

**Senior Technical Director**

Jim Hanson

**Executive Producer**

I. Kenneth Miller

**Producer**

N. Matthew Welton

**Production Coordinator**

Amanda P. Herman

**Sound Producers**

Kenny Miller  
Matt Welton

**Music Composition**

Eddie Chambers

**Sound & Music Design**

Brian Schmidt

**Graphic Designers**

Higashi Glaser Design

**Manual Design**

Beeline Group, Inc.

**Business Director**

Tracy Tattersall

**Development Support**

Scott Lawrence — Manager  
John Podlasek — Assistant Manager  
Baki Allen — Technical Supervisor

**Testing Team**

Dave Casso  
Gus Peterson  
Sirena Rana  
Glenn Levy

**Package Design**

Doublespace

**Manual Design**

Beeline Group, Inc.

**Special Thanks**

Melinda Fishman  
Stephen Gass

**Very Special Thanks**

Eugene Evans



Hookstone

# warranty

## VIACOM NEW MEDIA Limited Warranty

Viacom New Media warrants to the original purchaser only that the CD provided with this manual and the software program coded on it will perform in accordance with the descriptions in this manual when used with the specified equipment, for a period of 90 days from the date of purchase.

If the program is found defective within 90 days of purchase, it will be replaced. Simply return the CD with its original packaging to Viacom New Media or its authorized dealer along with a dated proof of purchase. Replacement of the CD, free of charge to the original purchaser (except for the cost of returning the CD), is the full extent of our liability.

EXCEPT FOR THE LIMITED WARRANTY ABOVE, VIACOM NEW MEDIA EXPRESSLY DISCLAIMS ANY AND ALL WARRANTIES, WHETHER ORAL OR WRITTEN, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OF THIRD PARTY RIGHTS.

Viacom New Media shall not be liable for incidental and/or consequential damages for the breach of any expressed or implied warranty including damage to property and, to the extent permitted by law, damages for personal injury, even if Viacom New Media has been advised of the possibility of such damages. Some states do not allow the exclusion or limitation of incidental or consequential damages or limitation on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you.

This warranty shall not be applicable to the extent that any provision of this warranty is prohibited by any federal state or municipal law which cannot be pre-empted. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

**VIACOM**  
newmedia™

1515 Broadway  
New York, NY 10036  
1-800-469-2539