RALLY BIKE

SOLDER SIDE		PARTS SIDE
GND	1	GND
GND	2	GND
+5V	3	+5V
+5V	4	+5V
	5	
+12V	6	+12V
POST	7	POST
COIN COUNTER B	8	COIN COUNTER A
COIN LOCKOUT B	9	COIN LOCKOUT A
SPEAKER (-)	10	SPEAKER (+)
	11	
VIDEO GREEN	12	VIDEO RED
VIDEO SYNC	13	VIDEO BLUE
SERVICE SW	14	VIDEO GND
TILT SW	15	
(COIN B)	16	COIN A
2P START	17	1P START
2P UP	18	1P UP
2P DOWN	19	1P DOWN
2P LEFT	20	1P LEFT
2P RIGHT	21	1P RIGHT
2P ACCEL BUTTON	22	1P ACCEL BUTTON
2P BRAKE BUTTON	23	1P BRAKE BUTTON
	24	
	25	
	26	
GND	27	GND
GND	28	GND

DIP SW 1

		1	2	3	4	5	6	7	8
TABLE TYPE		OFF							
UPRIGHT TYPE		ON							
MONITOR	Normal		OFF						
	Reverse		ON						
TEST MODE	Normal			OFF					
	Test			ON					
DEMO SOUND	Yes				OFF				
	No				ON				
PLAY CHARGE									
COIN A	1coin 1play					OFF	OFF		
	1coin 2play					ON	OFF		
	2coin 1play					OFF	ON		
	2coin 3play					ON	ON		
COIN B	1coin 1play							OFF	OFF
	1coin 2play							ON	OFF
	2coin 1play							OFF	ON
	2coin 3play							ON	ON

DIP SW 2

		1	2	3	4	5	6	7	8
DIFFICULTY	B	OFF	OFF						
Easy	A	ON	OFF						
	C	OFF	ON						
Difficult	D	ON	ON						
TYPE	Japan					OFF	OFF		
	USA					ON	OFF		
	EUROPE					OFF	ON		
	ROMSTAR					ON	ON		
TEST MODE	Normal							OFF	
	Test							ON	
CONTINUE PLAY	Yes								OFF
	No								ON