


ADJUSTMENT ON GAME PC BOARD (MASTER OF WEAPON G25 00513A)



☆ THE CONTROL OF THIS GAME USES ONE 8-WAY JOYSTICK AND 2 BUTTONS.

CONNECTOR (JAMMA)

| SOLDER SIDE      |   | COMPONENTS SIDE |                  |
|------------------|---|-----------------|------------------|
| GND              | A | 1               | GND              |
| GND              | B | 2               | GND              |
| +5V              | C | 3               | +5V              |
| +5V              | D | 4               | +5V              |
| -5V              | E | 5               | -5V              |
| +12V             | F | 6               | +12V (+13V)      |
| POST             | H | 7               | POST             |
| COIN COUNTER (B) | J | 8               | COIN COUNTER (A) |
| COIN LOCKOUT (B) | K | 9               | COIN LOCKOUT (A) |
| SPEAKER (-)      | L | 10              | SPEAKER (+)      |
|                  | M | 11              |                  |
| VIDEO G          | N | 12              | VIDEO R          |
| VIDEO SYNC       | P | 13              | VIDEO B          |
| SERVICE SW       | R | 14              | VIDEO GND        |
| TILT SW          | S | 15              |                  |
| (COIN 2)         | T | 16              | COIN 1           |
| 2P SELECT        | U | 17              | 1P SELECT        |
| 2P UP            | V | 18              | 1P UP            |
| 2P DOWN          | W | 19              | 1P DOWN          |
| 2P LEFT          | X | 20              | 1P LEFT          |
| 2P RIGHT         | Y | 21              | 1P RIGHT         |
| 2P AIR VULCAN    | Z | 22              | 1P AIR VULCAN    |
| 2P GROUND VULCAN | a | 23              | 1P GROUND VULCAN |
|                  | b | 24              |                  |
|                  | c | 25              |                  |
|                  | d | 26              |                  |
| GND              | e | 27              | GND              |
| GND              | f | 28              | GND              |

NOTE) BEFORE CHANGING THE DIP SWITCH, TURN THE POWER OFF.

◇ SETTING OF DIP SWITCH 1

(\*) : FACTORY SETTINGS

| SETTING                | POSITION         | 1   | 2   | 3   | 4   | 5   | 6 | 7   | 8   |
|------------------------|------------------|-----|-----|-----|-----|-----|---|-----|-----|
| GAME STYLE             | TABLE            | OFF |     |     |     |     |   |     |     |
|                        | UPRIGHT          | ON  |     |     |     |     |   |     |     |
| SCREEN ROTATION        | * NORMAL         |     | OFF |     |     |     |   |     |     |
|                        | REVERSE          |     | ON  |     |     |     |   |     |     |
| TEST MODE              | * NOMAL GAME     |     |     | OFF |     |     |   |     |     |
|                        | TEST MODE        |     |     | ON  |     |     |   |     |     |
| ATTRACT SOUND          | * WITH           |     |     |     | OFF |     |   |     |     |
|                        | WITHOUT          |     |     |     | ON  |     |   |     |     |
| PLAY PRICING<br>COIN 1 | * 1 COIN 1 PLAY  |     |     |     |     | OFF |   | OFF |     |
|                        | 2 COINS 1 PLAY   |     |     |     |     | ON  |   |     |     |
|                        | 3 COINS 1 PLAY   |     |     |     |     | OFF |   |     |     |
|                        | 4 COINS 1 PLAY   |     |     |     |     | ON  |   | ON  |     |
| PLAY PRICING<br>COIN 2 | * 1 COIN 2 PLAYS |     |     |     |     |     |   | OFF | OFF |
|                        | 1 COIN 3 PLAYS   |     |     |     |     |     |   | ON  |     |
|                        | 1 COIN 4 PLAYS   |     |     |     |     |     |   | OFF |     |
|                        | 1 COIN 6 PLAYS   |     |     |     |     |     |   | ON  | ON  |

◇ SETTING OF DIP SWITCH 2

| SETTING                                      | POSITION                        | 1   | 2   | 3   | 4 | 5   | 6 | 7   | 8   |
|--|---------------------------------|-----|-----|-----|---|-----|---|-----|-----|
| GAME DIFFICULTY<br>EASY(A) →<br>DIFFICULT(D) | * RANK B                        | OFF |     |     |   |     |   |     |     |
|  | RANK A                          | ON  | OFF |     |   |     |   |     |     |
|  | RANK C                          | OFF |     |     |   |     |   |     |     |
|  | RANK D                          | ON  | ON  |     |   |     |   |     |     |
| BONUS POINTS                                 | *500,000/1,000,000 PTS.         |     |     | OFF |   | OFF |   |     |     |
|  | 500,000/1,000,000/1,500,000 PTS |     |     | ON  |   |     |   |     |     |
|  | 500,000 PTS. ONLY               |     |     | OFF |   |     |   |     |     |
|  | NO BONUS                        |     |     | ON  |   | ON  |   |     | OFF |
| NUMBER OF PLAYERS                            | * 3                             |     |     |     |   | OFF |   | OFF |     |
|  | 4                               |     |     |     |   | ON  |   |     |     |
|  | 5                               |     |     |     |   | OFF |   |     |     |
|  | 6                               |     |     |     |   | ON  |   | ON  |     |
| PLAYER'S VEHICLE                             | * JET FIGHTER                   |     |     |     |   |     |   |     | OFF |
|  | MOTOR BIKE                      |     |     |     |   |     |   |     | ON  |

\* AS TO THE BONUS POINTS, REFER TO THE DISPLAY ON THE SCREEN. (500,000 PTS. .... ONE JET FIGHTER IS ADDED. 1,000,000 PTS. .... ONE JET FIGHTER IS ALSO ADDED)

